

e. Beckmann

Montageanleitung für Federteller

Artikelnummer: 204250 / 204260 / 204261

ACHTUNG!

Wir empfehlen, die Montage von einem Fachbetrieb durchführen zu lassen!

Lesen Sie sich vor Beginn der Montage diese Anleitung sorgfältig durch!

Gehen Sie Schritt für Schritt vor!

Halten Sie die Reihenfolge der einzelnen Schritte ein!

Andernfalls kann es zu Beschädigungen am Gerät kommen! Bei unsachgemäßer Montage kann der zuständige Sachverständige die Abnahme des gesamten Spielgerätes verweigern. Wird das Spielgerät durch unsachgemäße Montage beschädigt, ist der Hersteller nicht haftbar.

HINWEIS

204260 / 204261 benötigen kein Distanzstück. Daher entfallen Schritt 2 und 3!

MONTAGE

1. Federteller locker in die Feder eindrehen
2. Wieder etwas lösen, so dass an der Nase eine Öffnung entsteht
3. In diese Öffnung das Distanzstück per Hand fest eindrücken
4. Federteller so fest wie möglich drehen
5. Befestigen Sie jetzt den weiteren Aufbau am Teller



WARTUNG

Die Wartung richtet sich nach der allgemeinen Wartungsanleitung der Fa. E. Beckmann

e. Beckmann

Installation instructions for spring plates

Reference: 204250 / 204260 / 204261

ATTENTION!

We suggest that the installation is made by a professional playground equipment installer!

Please read this manual carefully before you start the installation!

Install the equipment step by step!

Keep the correct order of the steps!

Otherwise the equipment might be damaged! Improper installation may cause the rejection of the authorised expert of the whole play equipment.

If the equipment is damaged by improper installation the manufacturer may reject the guarantee.

ATTENTION

204260 / 204261 do not need a distance piece. Do not execute step 2 & 3!

INSTALLATION

1. Turn the spring plate into the spring
2. Lose the plate a littlebit that an opening appears
3. Insert the plastic distance piece in the opening with your hands only
4. Turn the spring plate as far as possible
5. Mount your equipment on the spring plate



MAINTENANCE

Maintenance has to be done acc. to the common maintenance guide provided by company E. Beckmann