

Montageanleitung Kriechröhre

Röhre ausrichten:

Röhre in ein Sand Bett auf den Boden legen,
Höhe ca. 10 cm über dem übrigen Gelände
Mit 2 % Gefälle um Stauwasser zu vermeiden.

Hügel errichten:

Röhre mit einem Bagger / Radlager zuschütten
Material ggfs., verdichten.

Rohrenden:

Können optional noch mit Stirnplatten aus Holz oder PE oder nach Belieben auch mit Holzbalken ausgestattet werden um zu verhindern dass Sand oder Erde vom Hügel in die Röhre gelangt.

Reinigung:

Mit einem Hochdruckreiniger oder Wisch Mob.

Installation Instruction for Creep Tunnels:

Align tube:

Put the tube in a sand bed on the floor,
Height: about 10 cm above the rest of playground terrain
With 2% inclination to prevent standing water.

Build the hill:

Put ground with an excavator over the the creep tunnel
Compaction the ground if necessary.

Tube ends:

Can also be optionally equipped with wooden or PE endboards or wooden beams to prevent sand or soil coming from the hill into the pipe.

Cleaning:

With a high pressure cleaner or wiping mob.