



Montageanleitung für Reckstangen

Artikelnummer: 204050 - 204070

ACHTUNG!

Wir empfehlen, die Montage von einem Fachbetrieb durchführen zu lassen!

Lesen Sie sich vor Beginn der Montage diese Anleitung sorgfältig durch!

Gehen Sie Schritt für Schritt vor!

Halten Sie die Reihenfolge der einzelnen Schritte ein!

Andernfalls kann es zu Beschädigungen am Gerät kommen! Bei unsachgemäßer Montage kann der zuständige Sachverständige die Abnahme des gesamten Spielgerätes verweigern. Wird das Spielgerät durch unsachgemäße Montage beschädigt, ist der Hersteller nicht haftbar.

MONTAGE

1. Prüfen Sie vor Beginn der Montage die Abstände zu benachbarten Geräten
2. Die Reckstangen werden mit einem Flansch fest verschweißt und mit einem Flansch lose geliefert um Längendifferenzen auszugleichen.
3. Die Reckstangen können beliebig gekürzt werden. Es müssen jedoch min. 25mm Stange im Flansch stecken.
4. Bei Rundholz ist es erforderlich eine plane Fläche von 12x5cm zur Montage zu schaffen.
5. Die Reckstange wird mit 4 Schrauben M8 befestigt. Diese werden nicht mitgeliefert.
6. Die Montage ist damit abgeschlossen.

WARTUNG

Die Wartung richtet sich nach der allgemeinen Wartungsanleitung der Fa. E. Beckmann

Stand: 05/2019



Installation instructions for Horizontal Bars

Reference: 204050 / 204070

ATTENTION!

We suggest that the installation is made by a professional playground equipment installer!

Please read this manual carefully before you start the installation!

Install the equipment step by step!

Keep the correct order of the steps!

Otherwise the equipment might be damaged! Improper installation may cause the rejection of the authorised expert of the whole play equipment.

If the equipment is damaged by improper installation the manufacturer may reject the guarantee.

INSTALLATION

1. Before you start check all distances and free spaces to other equipment
2. The bars will be delivered with one flange welded to the bar and the other not fixed to equalize differences in length
3. You may shorten the bar to your need, but you have to pay attention that at least 25 mm of the bar remain in the flange.
4. If you install the bars on round wood you have to prepare a flat area of 12x5cm for the flange
5. The horizontal bar has to be fixed with 4 bolts M8, that are not provided by us.
6. Installation is now finished.

MAINTENANCE

Maintenance has to be done acc. to the common maintenance guide provided by company E. Beckmann

Version: 05/2019